



**INSTALLATION AND OPERATING INSTRUCTION  
(COVER PAGE)**

ISSUE	DESCRIPTION OF CHANGE/CRN NO.	NO. OF ATTACHMENTS	DATE OF ISSUE	APPROVED BY:	
				PRODUCT SAFETY ENGG	DESIGN TEAM
00	RELEASE DRAWING	7	SEPTEMBER 11, 1996		
01	ADD ITEM 10,11,12,13 & REVISED ITEM 14. REVISED PAGE 3 FOR MAX. OUTPUT RATINGS. REVISED PAGE 4 FOR MECHANICAL OUTLINE SPECIFY MT. HOLE, ENGLISH/METRIC. REVISED PAGE FOR VENTILATION CONDITION. (G70874A)	7	AUGUST 17, 1997		
02	ADD SHEET 7, LPS25X-(CEF) VENTILATION CONDITION. (G70839C)	7	AUGUST 17, 1997		
03	REVISED PAGE 1, ITEM 1. K20011295C (WAS 033-61002222)	6	JUNE 22, 2001	<i>K. Chan Aug 1, 01</i>	<i>Pommy</i>



**NOTES:**

1. MATERIAL: WOODFREE 100G PAPER, DIM. 295mm x 210mm.
2. ALL CHARACTERS MUST BE CLEAR AND LEGIBLE.
3. ALL CHARACTERS MUST BE PRINTED BLACK ON WHITE BACKGROUND.
4. ASTEC NO. MUST BE PRINTED CLEAR AND LEGIBLY IN 3mm HEIGHT WITHIN RIGHT LOWER CORNER.
5. PRINTING MUST BE ON BOTH SIDES.

DESCRIPTION: INSTALLATION AND OPERATING INSTRUCTION FOR (MODEL NO.LPS252,LPS253,LPS254 AND LPS255)

PREPARED BY: LINDA CHAN



# INSTALLATION AND OPERATING INSTRUCTIONS FOR LPS252, LPS253, LPS254 AND LPS255

Revised Date: June 22, 2001

## BEDIENUNGSANLEITUNG

To comply with the published safety standards, the following must be observed when using this power supply.

Um den zur Zeit gültigen Sicherheitsbestimmungen zu genügen, müssen die nachstehenden Maßnahmen beim Einsatz dieser Netzgeräte berücksichtigt werden.

1. Maximum ambient temperature around the power supply must not exceed 50 deg C for all power supplies above except LPS253 (UL approval). For LPS253 ( UL approval ) , the maximum ambient temperature around the power supply must not exceed 50 deg C at 250W, 21A and 70 deg C at 125W, 10.5A.

Für alle o.g. Netzteile darf die maximale Umgebungstemperatur des Netzteiltes 50°C nicht überschreiten, ausser für das LPS253 (UL zugelassen). Für das LPS253, darf die maximale Umgebungstemperatur des Netzteiltes 50°C bei 250 Watt, 21A und 70°C bei 125 Watt, 10.5A nicht überschreiten.

2. The power supply is intended for use as a component part of other equipment. When installing the power supply and making input and output connections, the relevant safety standards e.g. UL 1950; IEC950; EN 60 950; VDE 0805; CSA 950 and CSA 22.2; No. 234 must be complied with, especially the requirements for creepage distances, clearances and distance through insulation between primary wiring and earth or secondary (SELV) wiring.

Ein Netzgerät ist ein Einbauteil in ein entsprechendes Gerät und bei Herstellung der elektrischen Verbindungen im und am Gerät sind die einschlägigen Bestimmungen wie z.B. UL 1950; IEC950; EN 60 950; VDE 0805; CSA 950; CSA 22.2; No. 234; zu beachten und einzuhalten, insbesondere die Anforderungen für Kriech und Luftstrecken und Dicke der Isolation zwischen Primär- und Schutzleiter- Kreis und Primär-zum Sekundärstromkreis (SELV-Kreis).

3. The output power taken from the supply must not exceed the rating given on the "Power Supply"

Die Ausgangsleistung darf die auf dem Netzgerät angegebenen Werte nicht übersteigen.

4. This power supply is suitable for different rated voltages. The switch over to the corresponding rated voltage which belongs to the specific appliance is done automatically in the appliance.

Dieses Netzgerät ist für verschiedene Nennspannung geeignet. Die Anpassung an die jeweilige Netzspannung, an die das Gerät angeschlossen ist, erfolgt automatisch im Gerät.

5. The fuse should only be replaced by F6.3AH, AC 250V, type 21606.3, by Littelfuse; type 50CF063H, by TRIAD; and type S501, by Cooper.

Die Sicherung darf nur durch den F6.3AH, 250V, type 21606.3 den Littelfuse, type 50CF063H den TRIAD und, type S501 den Cooper.

6. The earth wire must be connected only to the earthing point which is marked with the earth symbol.

Der Schutzleiter muß an der mit dem Schutzleitersymbol bezeichneten Stelle angeschlossen werden.

7. The disconnection from the line must be in the end system.

Die Trennung vom Netz muß im Endgerät durchgeführt werden.

8. This unit contains secondary outputs exceeding 240VA. When installing into the end system care must be taken that those secondary outputs and the appropriate wires may not be touched.

Das Netzgerät hat Sekundärausgänge mit Spannungen über 240VA. Beim Einbau in das Endsystem ist darauf zu achten, daß diese Sekundärausgänge und die dazugehörigen Leitungen nicht berührt werden können

9. The circuit wiring of the power supply is made in such a way that components like capacitors are positioned in front of the power supply fuse. Therefore the unit must be protected by a fuse in the installation system.

Die Schaltung des Netzgerätes ist so ausgelegt, daß Bauteile wie Kondensatoren vor der Sicherung des Netzgerätes liegen. Aus diesem Grunde muß unbedingt darauf geachtet werden, daß das Gerät durch eine Sicherung in der Installation abgesichert ist.

10. Hazardous voltages exist in the primary circuits. Disconnect power supply before servicing.

Gefährliche Spannung im Primärkreis. Vor der Reperatur die Verbindung zum Netz entfernen.



## INSTALLATION AND OPERATING INSTRUCTIONS FOR LPS252, LPS253, LPS254 AND LPS255

Revised Date: August 19, 1997

11. Beware of internal lethal voltages due to charged capacitors even after AC input is disconnected. A Minimum of 5 minutes should be allowed after AC input power is disconnected before handling.

Vorsicht mit totlichem strohm innerhimb diesem geraht wegengelladenen capacitors, selbst wenn AC strohm abgestellt ist. Fünf (5) minuten warten zum anfassen.

12. In case of failure, this power supply must be returned to Astec Authorized Service Station for Servicing to ensure compliance with safety requirements.

Sollte dieses geraht fehlen, nach Astec Authorized Service Station Zurücksenden zum insuren dass bedingungen noch gültig sind.

13. This power supply is CE marked following the provisions of the Low Voltage Directive, 73/23/EEC.

CE

14. The following additional items are for BAST approved unit only:

The Certified Equipment shall be installed in an enclosure such that:

- a) Any uninsulated electrical connections to and within the enclosure, other than those connected to protective earth, are within a restricted access location as defined in EN60950:1992:clause 1.2.7.3;
- b) Conductive parts of the enclosure, other than those connected to protective earth, shall have a minimum of 1.6mm creepage distance and 1.0mm clearance distance from any uninsulated electrical connection to or within the relevant apparatus;
- c) Conductive parts of the enclosure, other than those connected to protective earth, shall have a minimum of 5mm creepage distance and 4mm clearance distance from any parts conductively connected to an excessive voltage as defined in EN60950:1992:clause 1.2.8.3;
- d) A protective earth is provided for safety in accordance with EN60950:1992 Clause 2.5.

A mechanical and fire enclosure is provided, meeting the requirements of EN60950:1992 and 1&2: clauses 4.2.3; 4.2.4; 4.3.14 and 4.4.5

P/N: 033-61002222

Our Ref.: LPS252/253/254/255\OP.C

Issue Date : September 11, 1996

Page 2 of 6

SH 3/7



## INSTALLATION AND OPERATING INSTRUCTIONS FOR LPS252, LPS253, LPS254 AND LPS255

Revised Date: August 19, 1997

### INSTRUCTION SHEET FOR LPS25X SERIES (EINBAU ANLEITUNG FUER LPS25X SERIE)

#### OUTPUT RATINGS (AUSGANGS WERTE)

MODEL (MODEL)	OUTPUT VOLTAGE (AUSGANGS SPANNUNG) (V)	30 CFM FORCED AIR COOLING (BEILUFTSTOM MIT 30 CFM)	
		MAX. OUTPUT POWER WITH COVER (MAXIMALE AUSGANGS LEISTUNG MIT ABDECKUNG) (W)	MAX. OUTPUT CURRENT (MAXIMALER AUSGANGS STROM) (A)
LPS252	+ 3-6	250	50
LPS253	+ 6-12		21
LPS254	+ 12-24		16.6
LPS255	+ 24-48		10.4

#### CONNECTOR PIN DESIGNATION (STIFT BELEGUNG AM STECKER)

OUTPUT CONNECTOR (AUSGANGS STECKER)		LPS 252	LPS 253	LPS 254	LPS 255
BUS BAR	A	+ 3-6V	+ 6-12V	+ 12-24V	+ 24-48V
	B	COMMON	COMMON	COMMON	COMMON
SK3	PIN (STIFT) 1	+Sense	+Sense	+Sense	+Sense
	PIN (STIFT) 2	-Sense	-Sense	-Sense	-Sense
	PIN (STIFT) 3	Inhibit (Open)	Inhibit (Open)	Inhibit (Open)	Inhibit (Open)
	PIN (STIFT) 4	Inhibit (Closed)	Inhibit (Closed)	Inhibit (Closed)	Inhibit (Closed)
	PIN (STIFT) 5	Common	Common	Common	Common
	PIN (STIFT) 6	C.Share	C.Share	C.Share	C.Share
	PIN (STIFT) 7	POK	POK	POK	POK
	PIN (STIFT) 8	DC-OK	DC-OK	DC-OK	DC-OK
SK4	PIN (STIFT) 1	FAN (+)	FAN (+)	FAN (+)	FAN (+)
	PIN (STIFT) 2	FAN (-)	FAN (-)	FAN (-)	FAN (-)
SK5	PIN (STIFT) 1	+5V (Aux)	+5V (Aux)	+5V (Aux)	+5V (Aux)
	PIN (STIFT) 2	COM	COM	COM	COM

INPUT CONNECTOR (EINGANGS STECKER)		LPS 252	LPS 253	LPS 254	LPS 255
SK1	PIN (STIFT) 1	Neutral	Neutral	Neutral	Neutral
	PIN (STIFT) 2	Live (Spannungs- Fuehrend)	Live (Spannungs- Fuehrend)	Live (Spannungs- Fuehrend)	Live (Spannungs- Fuehrend)
	PIN (STIFT) 3	GND (ERDE)	GND (ERDE)	GND (ERDE)	GND (ERDE)

P/N: 033-61002222

Issue Date : September 11, 1996

Page 3 of 6

Our Ref: LPS252/253/254/255\OP.C


SH 4/7




# INSTALLATION AND OPERATING INSTRUCTIONS FOR LPS252, LPS253, LPS254 AND LPS255

Revised Date: August 19, 1997


Mechanical Outline For LPS25X Series  
Dimensions in cm unless otherwise specified



CUSTOMER MOUNTING HOLES (ALL DIMENSIONS IN CM, a=#6-32, b=m3)



Bottom View Of Chassis



Side View Of Chassis



INSTALLATION AND OPERATING INSTRUCTIONS  
FOR LPS252, LPS253, LPS254 AND LPS255


Revised Date: August 19, 1997

Ventillation Condition For LPS252, LPS253, LPS254 and LPS255

Fan Used: MINEBEA 2410ML-04W-B60

DC 12V 0.4A

DC Input For Fan During Testing: DC12V




or

Cover with Fan

Fan : MINEBEA 3108NL-04W-B30

DC 12V 0.19A





INSTALLATION AND OPERATING INSTRUCTIONS  
FOR LPS252, LPS253, LPS254 AND LPS255

Revised Date: August 19, 1997

or

Cover with 2 End Fan

Fan : MATSUSHITA FBK04F12U  
DC 12V 0.23A or

Fan : ADDA AD0412HB-C50  
DC 12V 0.13A

